

# Instruction book

# ALBIN AD-2

## List of Contents

	Introduction .....	3	
<b>Running</b>	Running-in .....	7	
	Preparation .....	7	
	Before starting .....	8	
	Starting .....	8	
	After Starting .....	9	
	Manoeuvring .....	9	
	Running .....	9	
	Stopping .....	10	
	Frost precautions .....	10	
	<b>Description and Maintenance</b>	General .....	10
		Fuel system .....	12
Lubricating system .....		15	
Cooling system .....		17	
Electrical system .....		18	
Reverse gear .....		20	
Reduction gear .....		21	
Anti-corrosion treatment .....		21	
Maintenance schedule .....		23	
<b>Installation</b>		General .....	25
		Engine bed .....	25
	Engine casing .....	25	
	Propeller equipment .....	26	
	Fuel system .....	28	
	Cooling system .....	29	
	Exhaust system .....	30	
	Electrical system .....	31	
<b>Technical Data</b>	.....	32	

The specifications and design information given in this book are not binding. We reserve the right to carry out modifications without previous notice.

# Introduction

The ALBIN AD-2 is a compact, short-stroke, modern and easy-to-install marine diesel with comprehensive standard equipment. Direct injection ensures excellent cold starting and low fuel consumption. These are some of the facts which make boating enthusiasts choose the ALBIN AD-2.

The engine is a 2-cylinder, 4-stroke diesel with overhead valves and direct injection. The fully balanced crankshaft, supported in three main bearings, together with the short stroke design, ensure smooth and vibration-free running whilst the specially designed inlet channels and multi-hole injection nozzle provide maximum fuel economy. Fuel to the injection pump is supplied by a feed pump which can also be operated by hand.

The standard 12-volt electric equipment consists of a 1.3 h.p. starter and a 90-watt (11 amps) generator. Alternatively, a 490-watt (38 amps) alternator which charges at idling speed can be fitted in lieu of the standard generator.

The convenient position of the starting handle, coupled with the decompression device and high inertia flywheel, ensures easy hand starting.

The engine and reverse gear are pressure-lubricated from a common lubrication system. The oil is supplied through drilled channels to the various lubrication points, eliminating the need for vulnerable external oil pipes.

Both the engine and the exhaust pipe are raw sea water cooled. The sea water cooling pump and automatic bilge pump are of the constriction type and are fitted with rubber impellers which are capable of handling solids. The bilge pump can also be used for cleaning the deck etc. The built-in thermostat maintains the correct working temperature.

The engine has a closed crankcase ventilation system, replaceable bearing shells, etc., giving the unit all the characteristics of the "engine of to-day". Behind the AD-2 construction lies more than 60 years' experience in the marine engine field.





Fig. 1

- 1 Lubricating oil filter
- 2 Feed pump for fuel oil with hand pumping lever
- 3 Lubricating oil dipstick for engine
- 4 Engine oil sump
- 5 Cooling sea water pump
- 6 Automatic bilge pump
- 7 Hand starting device in a convenient position
- 8 Fuel oil filter
- 9 Thermostat housing
- 10 Decompression lever
- 11 Injector nozzle
- 12 Oil filler cap
- 13 Exhaust manifold
- 14 Gearbox operating lever
- 15 Injection pump
- 16 Flywheel bell housing
- 17 Propeller shaft coupling
- 18 Reduction gear (the engine can be supplied with or without reduction gear)
- 20 Oil filler cap and venting for reduction gear






Fig. 2

- 21 Reverse gear
- 22 Gearbox operating lever
- 23 Venting valve for reverse gear
- 24 Inlet silencer with air filter
- 25 Crankcase ventilation
- 26 Inlet manifold
- 27 Generator
- 28 Starter


**AD-2 Lifeboat version**

The ALBIN Model AD-2 is approved as a lifeboat engine. The design varies to meet the regulations of different countries.

Fig. 3

This engine has

- 1 Vent pipe nipples with high-placed pipe openings.
- 2 Inlet manifold intake placed above the engine
- 3 Start pilot
- 4 Lengthened handstart shaft
- 5 Generator (can be supplied as optional extra)
- 6 Screws and oil dipsticks with special seals



# Running

## Running-in

When an engine leaves the factory it is partly run-in and has been carefully checked and bench-tested up to the specified output. It is recommended, therefore, that the engine be run for about 25 hours at 85 % of the full load and speed, in order to complete the running-in process. Afterwards, the oil in the engine and reduction gear must be changed when the engine is warm. Flushing oil should not be used. See "Maintenance Schedule", Page 23.

## Preparation

- 1 Fill the engine with oil through the oil filler cap in the valve cover, fig. 1, No. 12. Check the oil level with the dipstick on the port side of the engine, fig. 1, No. 3. (The reverse gear is pressure lubricated from the engine.)
- 2 Fill the reduction gear with oil through the filler cap, fig. 4, No. 1. Check the level with the dipstick, fig. 4, No. 2.
- 3 The governor and injection pump should be lubricated with the same oil as for the engine and reduction gear. The oil is filled through the oil filler cap, No. 1, until oil flows from the oil level plug No. 2, fig. 5.
- 4 Bleed the fuel system. This should be done even if the engine has not been used for a long time or if the fuel tank has been emptied during running. Slacken the banjo bolt, fig. 5 No. 3, on the fuel filter and pump fuel with the hand pump, fig. 5 No. 4, until a stream of fuel free from air bubbles flows from the bolt. Then tighten the bolt. Slacken the bleed screws No. 5, on the injection pump and repeat the operation, tightening the bleed screws when fuel flows free from air bubbles. Air in the fuel system is the main cause of starting troubles or irregular running. If the fuel system needs frequent bleeding, check fuel pipes, pipe fittings and tank in order to find any air leaks.




Fig. 4 1 Oil filler cap  
2 Oil dipstick  
3 Oil drain plug




Fig. 5 1 Oil filler cap  
2 Oil level plug  
3 Banjo bolt  
4 Hand pump  
5 Bleed screws




Fig. 6 1 Governor lever (mounted between the injection pump and the engine block)  
2 Button for extra starting fuel  
3 Stop lever




Fig. 7 1 Decompression lever  
2 Starting crank

## Before Starting

- 1 Check the oil level in the engine and reduction gear.
- 2 Check the fuel level in the tank and open the fuel cock.
- 3 Open the sea cock and adjust the three-way cock on the exhaust pipe for direct discharge overboard.
- 4 Grease the propeller shaft bearings.

## Electrical Starting

- 1 Put the reverse gear lever in neutral.
- 2 Insert the ignition key on the instrument panel.
- 3 Set the governor lever in the centre position, fig. 6. No. 1.
- 4 Press the button on the pump for extra starting fuel, fig. 6. No. 2.
- 5 Press the starter button on the instrument panel.

## Hand Starting

- 1 See Nos. 1, 3 and 4 above under the heading "Electrical Starting".
- 2 Set the decompression lever fig. 7. No. 1, in vertical position.
- 3 Insert the starting crank, fig. 7. No. 2.
- 4 Crank the engine as quickly as possible with the starting crank and return the decompression lever to the horizontal position while cranking.

## Start Pilot

If the engine has to be started in very cold weather, it may be fitted with a "start pilot" (see fig. 3). Remove the plug on the lower side of the intake pipe and fit the connection pipe for the start pilot. Start the engine at the same time as starting fuel is injected.

### After Starting

- 1 When the engine has started, set the governor to fast idling speed, about 700 r.p.m.
- 2 Check the oil pressure. The needle of the gauge should register in the green section.
- 3 If the engine is electrically equipped, check that the charging control light goes out when the engine revolutions are increased.
- 4 Set the three-way cock on the exhaust pipe in the middle position and check the cooling water circulation by seeing that the water is discharged overboard.

### Manoeuvring

Move the operating lever forward for running ahead and aft for running astern. When manoeuvring, keep the engine speed at about 800 r.p.m. Avoid sharp movements of the lever as this will cause unnecessary strain on the engine and reverse gear. Also, excessively slow movement of the lever will cause the clutch to slip. There is no risk of the engine racing when manoeuvring from ahead or astern to neutral as the engine is equipped with a centrifugal governor.

### Running

At regular intervals when running, check the oil pressure, the cooling water temperature and whether the dynamo is charging. The needles of the oil pressure gauge and cooling water thermometer should register in the green section at all times. The charging control light should glow only when the engine is running at low revolutions, but should extinguish when the revolutions are increased. This indicates that the dynamo is charging. The engine is constructed to allow continuous running at maximum revolution speed of 2,200 r.p.m. but, as shown on the chart, fig. 9, the fuel consumption is increased considerably when the engine is run at maximum revolutions. This not only applies to the AD-2, but to all engines and is dependent on the increased resistance of the water at higher speeds.




Fig. 9 Fuel consumption for AD-2 with 2:1 reduction gear and 3-bladed propeller 17" dia. X 14" pitch installed in a sea-going motorboat approximately 23' X 8'.




Fig. 10 1 Decompression lever  
2 Adjusting screws




Fig. 8 Instrument Panel

- 1 Switch box
- 2 Starter button
- 3 Charging control light
- 4 Oil pressure gauge
- 5 Cooling water thermometer
- 6 Stop control button

Key positions in switch box

	Key inserted	Key pulled out
0 ← 1	2	All current switched off
0 ↑ 1	2	Instrument panel lighting switched on
0 ↗ 1	2	Instrument panel lighting and other lighting switched on

### Stopping

- 1 **IMPORTANT!** Before stopping the engine, move the three-way cock on the exhaust pipe to discharge all the cooling water overboard. This should be done about 1/2 minute before stopping the engine and allows the exhaust pipe to be blown free from water and eliminates the risk of water entering the cylinders.
- 2 Stop the engine by moving the stop lever, fig. 6, No. 3, astern.
- 3 Switch off the electrical circuit by pulling out the key on the instrument panel. The engine must not be stopped by using the decompression device otherwise damage will result.

### Frost Precautions

- 1 After the engine has stopped, open the drain cocks on the cylinder block and exhaust pipe. Shut the bottom cock at the same time. If there is a cock fitted to the bilge pump inlet, this should also be shut, alternatively, lift the pipe above the water line.
- 2 When all the water has been drained, start the engine and run it for 1—2 minutes. Tests show that moisture in the pump is turned into ice crystals, but this has no detrimental effect while re-starting during severe cold. Running with closed cocks on the inlet side does not cause damage to the water pump impellers if the above stated time is not exceeded.

## Description and Maintenance

### General

The **cylinder block** is cast in one piece with chill-hardened bores which considerably lengthens the life of the engine.

The **cylinder head** is also cast in one piece and has replaceable exhaust valve seats.

The decompression device is built into the **valve cover**. By moving the lever, fig. 10, No. 1, to the vertical position, two adjusting screws, No. 2, are pressed against the exhaust valve rocker arms, the exhaust valves open and the engine is decompressed. See "Hand Starting" Page 8. To adjust the decompression device, both the exhaust valves should be closed. Tighten the adjusting screws against the rocker arms and then screw them down  $\frac{1}{2}$  to  $\frac{3}{4}$  turn, locking the screws with the lock nuts.

The **crankcase ventilation** is closed to prevent the escape of unpleasant fumes. The fumes are sucked back into the engine from the valve cover to the manifold inlet pipe through the reinforced plastic hose. A filter is fitted on the upper side of the valve cover.

The **filter**, fig. 11, No. 1, should be cleaned after about 300 hours.

The **valves** should be adjusted when the engine is cold. The valve clearance should be 0.3 mm/0.012" for both the inlet and exhaust valves.

The **exhaust valves** have stellite faces. Stellite is a very hard metal between 380 and 420 Hv which has excellent resistance to corrosion at high temperatures. The valve spindles are hard chromium plated.

The **inlet valves** are fitted with rubber sleeves to stop lubricating oil from leaking down the valve spindle into the cylinders.

The **pistons** are of light alloy and are fitted with three compression rings and two oil scraper rings. The top compression ring is hard chromium plated.

The **crankshaft** is manufactured from nodular iron, a material which is excellent for crankshafts as nodular iron combines the strength of steel with the fine bearing qualities of the pearlitic cast iron.

The **main bearings** consist of bearing shells of tin-aluminium.

The **connecting rods** are drop-forged and supplied with lead-bronze bushings and bearing shells of tin-aluminium.




Fig. 11 1 Filter for crankcase ventilation





Fig. 12 Valve adjustment



Fig. 13 Removal of air filter for cleaning (in white spirit)

Fig. 14 Injection pump

- 1 Oil filler plug
- 2 Oil drain plug
- 3 Oil level plug
- 4 Fuel priming hand lever
- 5 Connection for tachometer
- 6 Adjusting screws for idling and maximum r.p.m.
- 7 Press button for extra starting fuel
- 8 Stop control (lever)
- 9 Bleed screws
- 10 Pumping elements and pressure valves
- 11 Governor lever (mounted between injection pump and engine block)



The **camshaft** is made of cast iron with chill-hardened cams.

The engine is fitted with a large **inlet silencer** (fig. 13) with a filter which should be cleaned after about 200 hours running.

### Fuel system

The injection pump is mounted on the port side of the engine and is driven by the crankshaft via gears.

The governor which is combined with the injection pump is of the all speed centrifugal type and prevents the engine from racing in the event of the load being suddenly released.




Fig. 15 Fuel passage

### Fuel filter

The fuel filter cartridge cannot be cleaned but has to be replaced. By slackening the retaining bolt, fig. 16, No. 1, cover (2) can be removed and the filter cartridge (3) replaced by a new one. For bleeding the fuel system, use screw (4). This must be bled each time the filter cartridge is changed to extract air from the system. Nipple (5) is for the return excess fuel from the injectors. Normally the filter should be replaced after about 300 hours' running. If dirty fuel is used then the filter cartridge will require changing more frequently.




Fig. 16 Fuel filter

- 1 Filter retaining bolt
- 2 Cover base
- 3 Filter cartridge
- 4 Bleed screw
- 5 Union for return fuel

13




Fig. 17 Injector in section

### injector

The injector is required to inject fuel at exactly the right moment in spite of the high pressure in the cylinder. The fuel flow, which is adjusted by the fuel pump, is forced through a hole in the nozzle holder down to the nozzle. When the correct pressure is reached, the needle rises and allows the fuel to pass through four very fine holes. These carefully-calibrated nozzle holes, together with the well-designed air channels, ensure perfect atomisation of the fuel and compressed air in the cylinders.

**NOTE: NO SERVICING OR ADJUSTMENT TO THE INJECTION EQUIPMENT MUST BE CARRIED OUT BY ANYONE OTHER THAN A DIESEL SPECIALIST.**

The fuel filter cartridge can be replaced by the user but for other details, we recommend that a diesel workshop be contacted.

### Fuel

The Model AD-2 is a fast running diesel and requires a fuel with cetane index 45 which is suitable for fast running engines. This is the same fuel as is used in trucks, buses and all high speed automotive diesel engines. There is a great risk of the injectors carbonizing resulting in imperfect combustion if unsuitable fuel is used.




Fig. 18 Injection timing and T.D.C. are marked on the flywheel. By removing the cover to which the rear eye bolt is fitted, on top of the flywheel bell housing, these marks are easily visible.

## Lubricating system

The engine and reverse gear are lubricated by means of a common lubricating system. It is sufficient to fill and check the oil level in the engine, thus ensuring the reverse gear is also lubricated. In the oil sump there is a strainer through which the oil passes before it is sucked up into the lubricating oil pump. This is a gear pump with a relief valve. The oil is then forced through an oil filter of the full-flow type. Consequently, all lubricating oil passes through the filter and drilled oil channels before it reaches the different parts to be lubricated. If the filter is clogged, then the cartridge requires replacing but a relief valve will open and the engine will be lubricated direct from the oil pump. Should the oil pressure fall, it could mean that the lubricating oil filter is clogged.

### Checking of oil level

Before starting, check the oil level every day with the dipstick at the port side of the engine fig. 1 No. 3. If the oil level does not reach the lower mark on the dipstick, additional oil must be poured into the oil filler pipe on the valve cover of the engine, fig. 1, No. 12.

The oil consumption will be exceptionally high if the oil level is above the top mark on the dipstick.

The oil capacity of the engine/reverse gear, including that of the lubricating oil filter is 3.3 litres (5.8 imp. pints, 7.0 US pints).

### Engine and reverse gear oil change

The oil should be changed every 100 hours or once per season if shorter. However, during the running-in period, the oil should be changed every 25 hours, and it should always be done while the engine is hot. During the running-in period (about 100 hours) the lubricating oil consumption is higher than normal and, therefore, has to be checked more often. The oil is removed by being sucked out through the oil dipstick hole by means of the oil bilge pump supplied in the tool kit with the engine.

NEVER USE FLUSHING OIL

### Suitable oils

Quality	Service DM
Viscosity at temperatures between —10°C and +10°C (14°F and 50°F)	SAE 20
at temperatures above +10°C (50°F)	SAE 30
BP	Energol Diesel S1
Caltex	RPM Delo Super Special
Castrol	Deusol CR 30
Esso	Essolube HDX
Gulf	Gulflube Motor Oil HD
Mobil Oil	Mobil DTE Marine Oil No. S-130
Shell	Rotella T 30
Valvoline	Super HPO




Fig. 19 Replacing of the filter

### Replacing of the filter cartridge

The lubricating oil filter cartridge cannot be cleaned so must be replaced (fig. 19) every 300 hours or once every season.

- 1 Remove the old filter cartridge.
- 2 Oil the gasket of the new filter cartridge and check that the facing surfaces are clean and undamaged.
- 3 Tighten the filter cartridge carefully by hand and wipe off any oil around the filter.
- 4 Run the engine and check that there are no oil leaks.

### Reduction gear oil change

The reduction gear, if fitted, is lubricated separately. Oil should be filled up to the dipstick mark. Check the oil level each time the oil level in the engine is checked. Change the oil every 300 hours, but during the running-in period, it should be changed after the first 25 hours. Change the oil while the engine is warm. Drain the oil through the plug at the lower part of the gearbox (fig. 4, No. 3). Use the same oil as for the engine. The reduction gear contains 0.25 litres of oil (0.44 imp. pints, 0.53 US pints).

### Injection pump and governor oil change

The governor and injection pump have the same oil supply. Change the oil while the engine is warm every 100 hours or once every season, by draining it through the plug, fig. 14, No. 2, fitted under the pump. Fill up through the oil filler plug on the top of the pump, fig. 14, No. 1, until oil flows from the oil level plug fig. 14, No. 3, using the same oil as for the engine.



## Cooling system

The engine is direct sea water cooled. The cooling water pump is mounted on the forward end of the engine and is coupled to the automatic bilge pump. They are both "vane" pumps with rubber impellers which are capable of handling solids.


The automatic bilge pump has a capacity of approximately 15 litres (26 imp. pints, 31.5 US pints) per minute at full speed and approximately 4 litres (7 imp. pints, 8.5 US pints) per minute at idling. If there is no water in the boat to bilge, the impeller is lubricated by water entering through a hole in the wall between the cooling water pump and the bilge pump.

The pumps are fitted with Teflon impregnated bronze bearings which are lubricated by water.


A damaged impeller will probably cause the cooling water supply to stop. This can happen if the engine is run too long without a water supply or if the impeller has frozen. See "Frost Precautions" Page 10. If damaged, the impeller must be replaced and this can be accomplished by removing the pump cover, the bilge pump and the wall between the pumps (see fig. 21).

The thermostat is enclosed in the thermostat housing. By removing the housing cover the thermostat is accessible for replacement (fig. 22). Cooling water is distributed by the thermostat so that the engine block and cylinder head maintain the proper working temperature.


From the connection No. 9, fig. 20, a pipe must be taken to a three-way cock which should be fitted to the exhaust pipe (see installation Drawing on Page 30). The cooling system has to be checked about every 400 hours or once every season. The checking should include pipes, thermostat, impellers and temperature gauge.



**Fig. 20** 1 Inlet with non-return valve — bilge pump  
2 Outlet — bilge pump  
3 Inlet — cooling water pump  
4 Outlet — cooling water pump  
5 Distributor cooling water pipe — engine/thermostat  
6 Cooling water pipe to engine exhaust manifold  
7 Cooling pipe to thermostat  
8 Thermostat housing  
9 Connection for cooling water pipe to three-way cock on exhaust pipe



**Fig. 21** Water pump impeller replacement  
1 Impeller




**Fig. 22** Thermostat replacement

## Electrical system

The engine is fitted with a 12-volt electrical system.


It is supplied with a starter of 1.3 h.p., 90 watt (11 amp) generator, voltage cut-out regulator and instrument panel as standard.

If extra output is required, a 490 watt (38 amp) alternator can be fitted in place of the standard 90 watt (11 amp) generator. This has the advantage of charging even when the engine is idling.



**Fig. 23**

Wiring diagram 2K-250 for an engine with the standard 90-watt (11 amp) generator.




**Fig. 24**

Wiring diagram 2K-251 for an engine with a 490-watt (38 amp) alternator and built-in rectifier.

- 1 Switch box
- 2 Charging control light
- 3 Starter button
- 4 Instrument lights
- 5 Lighting
- 6 Starter
- 7 Battery
- 8 90-watt (11 amp) generator
- 9 490-watt (38 amp) alternator. NOTE. The alternator must not be run unless it is connected to relay and battery
- 10 Voltage control cut-out regulator
- 11 Fuse box
- ⊥ Engine block

The cable cross section area should be 2.5 mm<sup>2</sup> (0.004 sq. in.) if not otherwise stated. If cable length exceeds 5 meters (16') a larger cable area should be used.



**Fig. 25** 1 Adjusting screw and locknut for neutral position  
 2 Adjusting ring for disc clutch  
 3 Locking set-bolt for adjusting ring  
 4 Adjusting screw and locknut for brake band

### Reverse Gear

The reverse gear is of the planetary type with a positive neutral position. It is lubricated with oil from the engine.

#### Adjustment for running ahead

Adjustment of the disc clutch for running ahead is carried out by turning the adjusting ring fig. 25, No. 2, clockwise, after slacking the locking set-bolt No. 3. Usually it is sufficient to turn the ring so that the locking set-bolt fits into the first or second notch after the previous one used. Then tighten the locking set-bolt.

NOTE. Check the adjustment after the first 50 hours running.

#### Adjustment for running astern

Slacken the locking nut on the adjusting screw No. 4. Turn the screw 1/4 to 1/2 turn clockwise which is a normal adjustment. Tighten the locking nut.

#### Adjustment of neutral position

Slacken the locking nut on screw No. 1. Have the engine idling with the operating lever in the neutral position. Turn the screw clockwise or anticlockwise until the propeller shaft stops rotating and tighten the locking nut. NOTE. This adjustment must be carried out when the engine has reached its normal working temperature.

If the engine is installed in a sailing vessel, mark clearly the position of the propeller blades on the propeller shaft coupling. When sailing, turn the propeller shaft so that the propeller blades are vertical and hidden behind the stern post, then lock the propeller shaft in this position by moving the operating lever in the position for running ahead. The propeller then gives minimum drag in the water. If the propeller shaft rotates when sailing, it causes damage. The reverse gear is pressure lubricated from the engine and if the engine is not running, the reverse gear is not lubricated.

#### Reduction gear

The engine can be supplied with three different ratios:

Direct drive 1:1 ratio

Reduction gear 2:1 ratio

Reduction gear 2.7:1 ratio

By selecting the correct ratio, an engine can be supplied with the correct number of propeller revolutions suitable for your boat. A small light boat can be fitted with direct drive, but a heavier boat should have reduction gear in order to obtain good propeller efficiency.

The reduction gear is not lubricated by the engine lubricating system (see "Lubricating system", Page 16).

#### Anti-corrosive treatment

When an engine is not run for a long period, e.g. during the winter, corrosion damage can occur in both the combustion and cooling systems. Engine life can be considerably extended by thorough anti-corrosive treatment.

#### Internal components

Run the engine until it has reached normal working temperature. Drain the oil from the engine, oil filter, governor/injection pump and reduction gear. Pour in anti-corrosive oil. Empty the fuel tank and pour in a small quantity of anti-corrosive fuel. Start the engine and run it for about 10 minutes. Stop the engine and drain the anti-corrosive oil from the engine, governor, injection pump, oil filter and reduction gear. Empty the fuel tank and fuel filter. Cover intake and exhaust pipe openings.

#### Anti-corrosive oil

Shell	Ensis Oil 30
Esso	Rust Ban 623
Gulf	Gulf NO-Rust Engine Oil No. 1
Caltex	Preservative Oil 30
BP	Energol Protective Oil 30
Castrol	Castrol Storage Oil
Mobil Oil	Mobil Kote 503
Valvoline	Tectyl 876

#### Anti-corrosive fuel

Shell	50 % Ensis Oil 10 W, 50 % white spirit
Esso	1/3 Rust Ban 623, 2/3 Autodiesel
Gulf	Gulf Calibrating Oil 45A
Caltex	Rustproof Oil
BP	Energol LM or Energol LM-C
Castrol	Castrol Calibration Oil 8327
Mobil Oil	Mobil Kote 203
Valvoline	1/3 Tectyl 876, 2/3 Autodiesel

21

#### Anti-corrosive oil — Cooling jackets

Shell	Donax C
Esso	Rust Ban 392 (not emulsifying)
Gulf	Gulf Cut 51 A
Caltex	Radiortext
BP	Soluble Oil EH Energol SB 4
Castrol	Dickool 5 (1/2 %)
Mobil Oil	Solvac 2 (emulsifying) Mobil Kote 203 (not emulsifying, water superseding)
Valvoline	Tectyl 81 D Base

#### Cooling jackets

Unscrew the connection between the cooling water pipe and thermostat cover and remove the cover, thermostat and cooling water pipe. Plug the openings in the pump and outlet pipe (see Page 17). Open all drain cocks and let out the water. Close the cocks and pour anti-corrosive oil into the thermostat housing until the whole system is filled. Replace the thermostat cover.

NOTE: The cooling water pump and bilge pump must not come into contact with the anti-corrosive oil. They are made wholly of stainless material and the rubber impellers could be damaged by the anti-corrosive oil.

#### Electrical units

The electrical units, such as the starter and generator, are preserved by lacquers so that they can be stored in damp and cold air. It is not necessary, therefore, to remove these units from the engine to be stored in a heated room. Every second year the electrical units should be overhauled by a specialised workshop.

#### When preparing the engine for use again

Draw off the anti-corrosive oil from the cooling jackets and refit the thermostat and all pipes. Fill up with lubricating oil to the required amount and ensure that there is fuel in the tank, and the engine is ready to be operated.

## MAINTENANCE SCHEDULE

		Daily	Every 100 hours <sup>1)</sup>	Every 200 hours <sup>1)</sup>	Every 300 hours	Every 400 hours	Every 1000 hours
<b>Lubrication</b>	Check the oil level in engine	×					
	Check the oil level in reduction gear	×					
	Change the oil in engine		×				
	Change the oil in reduction gear				×		
	Change the oil in governor and injection pump		×		×		
	Change the lubricating oil filter cartridge				×		
<b>Fuel system</b>	Change the fuel filter				×		
	Check the injectors					×	
<b>Cooling system</b>	Check the cooling system					×	
<b>Electrical system</b>	Check the acid level in the battery	×					
	Check the generator and starter						×
<b>Reverse gear</b>	Check the reverse gear		×				
<b>General inspection and overhaul</b>							
	Check the valve clearance			×			
	Clean the inlet silencer			×			
	Clean the oil strainer						×
	Clean the crankcase ventilation system						×
	Decarbonise and grind the valves				×		×

<sup>1)</sup> or at least once every season

23

## Installation

- 1 Operating lever. Operating power on handle: Ahead 8 kg. (17.5 lb), astern 7 kg. (15.5 lb). Torque max. 4.4 kgm. (32 ft. lb.)
- 2 Connection for start pilot
- 3 Governor lever. Length 143 mm (5.5<sup>5</sup>/<sub>8</sub>" ), angular movement 30°. Torque 0.5 kgm. (3.5 ft. lb.)
- 4 Injection pump stop lever. Length 45 mm (1<sup>3</sup>/<sub>4</sub>" ), angular movement 67°. Torque 0.04 kgm. (0.3 ft. lb.)
- 5 Connection for cooling water thermometer, 1/2" BSP
- 6 Connection for exhaust pipe, 1 1/2" BSP
- 7 Three-way cock for cooling water outlet. Connection for rubber hose with 3/4" internal diameter
- 8 Connection for oil pressure gauge, 1/2" BSP
- 9 Connection for fuel feed pipe, diameter 7/5 mm (1/4")
- 10 Connection for tachometer. SAE regular drive
- 11 Bilge pump inlet. Connection for rubber hose with 3/4" internal diameter
- 12 Cooling water inlet. Connection for rubber hose with 3/4" internal diameter
- 13 Bilge pump outlet. Connection for rubber hose with 3/4" internal diameter




Fig. 26

**General**

To get the best out of your engine, correct installation is essential. The engine is carefully tested before leaving the factory and many faults arise due to bad installation. You are advised, therefore, to contact a boatyard to check the installation by skilled marine engineers.


**Engine bed**

The engine bed should be robust and, if possible, of oak, the weight being spread over as many timbers as possible.

The bed should be fixed to the hull by through-bolts.

**Mounting**

As standard, the engine is delivered with fixed mountings, but it can also be delivered with rubber mountings.




**Fig. 27** Engine bed  
The same engine bed can be used for fixed mounting and rubber mounting due to easily exchangeable mounting brackets.

**Engine compartment**

A series of tests has been carried out and, as a result, an effective sound insulating engine case has been designed. Fig. 28 shows the recommended design which has given good test results.

To obtain optimal insulation, it is advisable to place a bulkhead on each side of the engine. These bulkheads should cover the whole space from the cabin floor down to the planking and, of course, they have to be lined with the same sound insulating material as the engine case. In order to provide the engine with sufficient air, it is necessary to fit a 2" internal diameter rubber hose through the bulkhead aft.




**Fig. 28**

**Propeller Equipment**


A flexible propeller shaft coupling must be used for a rubber mounted engine which has fixed stern bearings. If the propeller shaft between the inner stern bearing and the coupling is shorter than 0.3 m (12") it is also necessary to use flexible mounted bearings.

**Propeller**

Vibrations can be caused by too small a propeller aperture. The measurements given in fig. 31 should not be reduced. ALBIN MOTOR will make a propeller calculation for a special installation without charge on request.






**Fig. 29** Fixed mounting  
Measurements in mm



**Alignment**

Check the alignment of the engine and propeller shaft two/three days after launching. This is particularly important for engines with fixed propeller shaft couplings. Loosen the coupling bolts and separate the coupling halves slightly.


- 1 Check for misalignment between the centre lines by drawing the halves apart so that the guide boss and recess are free. When pressed together, the guide boss and recess should fit. See fig. 32.
- 2 Check the angle and centre lines by inserting a feeler gauge, 0.05 mm (0.002") between the halves. Press them together so that the feeler gauge touches. This measurement check must be made both in the horizontal and vertical plane. The couplings should then be rotated and checked at 90° intervals.



**Fuel system installation**

**Fig. 34**

- 1 Fuel tank
- 2 Tank filler cap
- 3 Tank filler neck
- 4 Hose clamps
- 5 Vent pipe
- 6 Skin fitting for vent pipe with filter
- 7 Fuel cock
- 8 Fuel pipe
- 9 Flexible hose between engine and fuel pipe
- 10 Coarse filter
- 11 T-pipe



### Cooling water installation




Fig. 35


- 1 Strainer
- 2 Inlet skin fitting
- 3 Sea cock
- 4 Union
- 5 Rubber hose
- 6 Hose clamp
- 7 Inlet union for cooling water pump
- 8 Outlet skin fitting
- 9 Strainer for bilge pump
- 10 Union

29

### Exhaust system installation

Fig. 36

- 1 Exhaust pipe flange
- 2 Bend
- 3 Three-way cock for cooling water outlet
- 4 Pipe from thermostat to three-way cock
- 5 Connection at thermostat
- 6 Bend
- 7 Heat resistant rubber exhaust hose
- 8 Hose clamp
- 9 Silencer connection
- 10 Silencer of neoprene rubber
- 11 Connection to skin fitting
- 12 Exhaust pipe skin fitting




When a special heat resistant rubber exhaust hose is used, cooling water must be passed out through the exhaust system all the time. If a neoprene rubber silencer is used, it must be mounted at least 90 cm (35") from the flange of the exhaust manifold and the space between the cooling water inlet and the silencer must be at least 60 cm (24"). The silencer must not be installed close to the hull, timber, etc., but must be freely suspended.

## Electrical system

Fig. 37

- 1 Generator
- 2 Voltage cut-out regulator
- 3 Starter motor with solenoid
- 4 Starter button
- 5 Connection for inspection lamp
- 6 Switch box and key
- 7 Horn button
- 8 Charging control light
- 9 Instruments with lights
- 10 Fuse box
- 11 Distribution terminals
- 12 Main switch
- 13 Battery
- 14 Starboard light — green (10 watt)
- 15 Port side light — red (10 watt)
- 16 Mast headlight — white (15 watt)
- 17 Stern light — white (15 watt)
- 18 Fog horn
- 19 Interior lighting
- 20 Search light
- 21 Engine body



### Battery

Standard capacity 12-volt 43 amp/hr

### Electrical wires

Ensure that the wires are of the correct thickness. For all lighting a twinwire with an area of 2.5 mm<sup>2</sup> (0.004 sq.in.) should be used. Should the length of wire exceed 5 m (16'), a thicker wire must be used. The feeder cable from the battery is a single wire 6 mm<sup>2</sup> (0.01 sq.in.) and the wire between the battery and starter and between the engine body and battery is a single wire 35 mm<sup>2</sup> (0.055 sq.in.).

31

## Technical data

Output SAE-hp/rpm .....	20/2200	Oil quantity, reduction gear, litres (imp./US pints) .....	0.25 (0.44/0.53)
Output DIN-hp/rpm .....	16/2200	Oil quality .....	Service DM
Torque max. kgm/rpm (ft.lb./rpm) .....	5.3/2000 (37.6/2000)	Viscosity	
Bore, mm. (ins.) .....	90 (3.54)	Temperatures —10°C up to +10°C (14°F —50°F) .....	SAE 20
Stroke, mm. (ins.) .....	82 (3.23)	Temperatures +10°C and above (50°F) ..	SAE 30
Swept volume, litres (cu.in.) .....	1.044 (63.7)	Oil pressure by warm engine kg/cm <sup>2</sup> (psi)...	2—3 (29—43)
Compression ratio .....	17.5:1	Oil pressure, minimum, kg/cm <sup>2</sup> (psi) .....	0.5 (7)
Compression pressure kg/cm <sup>2</sup> (psi) at 320 rpm	21 (300)	Lubricating oil filter .....	Fram PH-966
Revolutions, idling, rpm .....	550		
Engine rotation (seen from the stern)			
without reduction gear .....	Anti-clockwise		
with reduction gear 2:1 and 2.7:1 respectively .....	Clockwise		
Maximum inclination .....	13°		
Valve clearance, cold engine			
Intake, mm (ins.) .....	0.3 (0.012)		
Exhaust, mm (ins.) .....	0.3 (0.012)		
Decompression device, pressing down of valves (number of turns of the adjusting screws) .....	1/2—3/4		
Weight, kg (lb) .....	235 (520)		

### Fuel system

Combustion system .....	Direct injection
Injection pressure kg/cm <sup>2</sup> (psi) .....	165 (2350)
Injection timing (marked on the flywheel) ...	23° before TDC
Feed pump, suction lift m (ft.) .....	1.5 (5)
Fuel diesel oil with cetane index .....	45

### Lubricating system

Oil quantity, engine — reverse gear, litres (imp./US pints)	
excluding oil filter .....	3 (5.3/6.35)
including oil filter .....	3.3 (5.83/7.0)

### Cooling water system

Thermostat begins to open .....	77°C (170°F)
Bilge pump	
capacity at idling, litres/min (imp./US pints)	4 (7/8.5)
capacity at full load, litres/min (imp./US pints) .....	15 (26/31.5)

### Electrical system

Battery voltage, volt .....	12
Battery capacity, amp/hr .....	43
Starter output, hp .....	1.3
Generator output, watt (amp) .....	90 (11)
Alternator output, watt (amp) .....	490 (38)

### Recommended torque

Cylinder head nuts, kgm (ft. lb) .....	10 (72)
Connecting rod bearing bolts, kgm (ft. lb) ...	5.2 (37)
Main bearing bolts, kgm (ft. lb) .....	10 (72)
Flywheel bolts, kgm (ft. lb) .....	2.6 (19)
Injector, kgm (ft. lb) .....	2.5 (18)



Effekt, SAE-hk/r/m .....	20/2200	Vikt	
Effekt, DIN-hk/r/m .....	16/2200	Motor med backslag, kg .....	225
Vridmoment, kpm vid 2000 r/m .....	5,3	Motor med backslag och reduktionsväxel	245
Arbetsätt .....	Fyrtakt	Reduktionsväxel, utväxlingsförhållande	2,04:1 el. 2,7:1
Varvtal		Bränsleförbrukning	
Max, r/m .....	2200	Full last, liter .....	3,5
Tomgång, r/m .....	550	Marschfart, liter .....	ca 1,5
Största lutning, ° .....	13	Kompressionsförhållande .....	17,5 : 1
Rotationsriktning (sett akterifrån)		Kompressionstryck, kp/cm <sup>2</sup> vid 320 r/m	21
Utan reduktionsväxel .....	Moturs	Cylindervolym, liter .....	1,044
Med reduktionsväxel .....	Medurs		

CYLINDRAR OCH KOLVAR

Antal cylindrar .....	2	Kolvringsgap	
Cylinderdiameter, mm .....	90	Kompressionsring nr 1, mm .....	0,356/0,483
Slaglängd, mm .....	82	Kompressionsring nr 2 och 3, mm .....	0,279/0,406
Kolvmaterial .....	Lättmetall	Oljeskraping nr 1 och 2, mm .....	0,279/0,406
Kolvspel, max, mm .....	0,12	Kolvringsspel - bredd	
		Kompressionsring nr 1, mm .....	0,114/0,063
		Kompressionsring nr 2 och 3, mm .....	0,089/0,038
		Oljeskraping nr 1 och 2, mm .....	0,089/0,038

VENTILER

Ventildiameter		Ventilsätets och ventilens vinkel	
Inloppsventil, mm .....	36	Inloppsventil, ° .....	30
Avgasventil, mm .....	32	Avgasventil, ° .....	30
Ventilspel, kall motor		Inloppsventilen	
Inloppsventil, mm .....	0,3	öppnar, ° före ö.d. ....	18
Avgasventil, mm .....	0,3	stänger, ° efter u.d. ....	52
Ventilspindelsspel		Avgasventilen	
Inloppsventil, mm .....	0,05	öppnar, ° före u.d. ....	54
Avgasventil, mm .....	0,05	stänger, ° efter ö.d. ....	16

LAGERSPEL

Vevlagerspel, mm .....	0,05 - 0,09	Ramlagerspel, mm .....	0,05 - 0,09
------------------------	-------------	------------------------	-------------

FÖRBRÄNNINGSSYSTEM

Förbränningssystem .....	Direkt- insprutning	Bränsle	
Insprutningspump, Simms .....	P 4717/1	Specifik vikt vid 15° C .....	0,8 - 0,9
Insprutare, Simms .....	N 1172 A	Viskositet vid + 20° C, cst .....	3,5
Spridarhållare, Simms .....	HB 60S40	Flampunkt, °C .....	70
Spridare, Simms .....	NL 123 (4 hål)	Lägsta flyttemperatur A.S.T.M.	
Öppningstryck, insprutare, kp/cm <sup>2</sup> .....	165	vinter, °C .....	- 30
Förinsprutningsvinkel (märkt på sväng- hjulet), ° före ö.d. ....	23	sommar, °C .....	- 20
Insprutningsmängd, fullvarv (200 in- sprutningar vid 600 r/m), cm <sup>3</sup> .....	6,3 - 6,4	Vattenhalt .....	Ingen
Bränslefilter, Simms .....	FH 20	Askhalt, max, % .....	0,001
Filterinsats, Simms .....	A 18066	Svavelhalt, max, % .....	0,5
Matarpump, AC .....	Membranpump	Kokstal enligt Conradson, max .....	0,03
Matarpump, max sughöjd, m .....	1,5	Effektivt värmevärde, kcal/kg .....	10200
Regulator .....	Allvarvsregu- lator av centrifugaltyp	Cetantal, min .....	52

SMÖRJSYSTEM

Oljepump, typ .....	Kugghjuls- pump	Oljetryck Varm motor, kp/cm <sup>2</sup> .....	2 - 3
		Minimum, kp/cm <sup>2</sup> .....	0,5
Oljefilter, Fram .....	PH-66	Oljekvalitet .....	Service DM
Smörjsystem		Viskositet	
Motor .....	Trycksmörjning	+ 20 <sup>o</sup> C och över .....	SAE 30
Backslag .....	Trycksmörjning	- 10 <sup>o</sup> C till + 20 <sup>o</sup> C .....	SAE 20
Oljemängd			
Motor och backslag, liter .....	3		
Reduktionsväxel, liter .....	0,3		

KYLSYSTEM

Kylvattenpump .....	Pump med gummiimpeller	Länsump .....	Pump med gummiimpeller
Termostat		Kapacitet	
Öppningstemperatur, °C .....	77	Vid fullvarv, liter/minut .....	15
Helt öppen, °C .....	86,5	Vid tomgång, liter/minut .....	4

ELSYSTEM

Batterikapacitet, Ah (med likströms- generator) .....	43	<u>Alternativ utrustning</u>	
Startmotor, Bosch (effekt 1,3 hk).....	GE(R) 12 V 1,3 PS	Växelströmgenerator, Bosch .....	LJ 328/12 J 14K 1 R 14 V 35 A 20
Generator, Bosch (effekt 90 W) .....	EH(R) 14 V 11 A 19	Relä, Bosch .....	RS/ADN 1/14/1
Relä, Bosch .....	TA 14 V 11 A	Batterikapacitet, Ah .....	133
Spänning, V .....	12	Generatoreffekt, W .....	490

ERFORDERLIGT ÅTDRAGNINGSMOMENT

Cylinderlocksmuttrar, kpm (ftlb) .....	10 (72)	Svänghjulsbultar, kpm (ftlb) .....	2,6 (19)
Vevstaksmuttrar, kpm (ftlb) .....	5,2 (37)	Insprutare, kpm (ftlb) .....	2,5 (18)
Ramlagerbultar, kpm (ftlb) .....	10 (72)		

PA/10

1976-02-12

Distribution Arende

Ungefärligt  
tillverkningsår

Motornummer

1100	1925
1200	1926
1400	1927
1600	1928
1900	1929
2200	1930
2600	1931
2800	1932
3000	1933
3300	1934
3700	1935
4100	1936
4700	1937
5100	1938
5600	1939
6400	1940
6900	1941
7400	1942
7700	1943
8200	1944
8500	1945
8900	1946
9800	1947
14.000	1947-1948
15.000	1948
16.000	finns inga kort på dessa nummer
17.000	" " " " " "
18.000	1948
19.000	1949
20.000	1949-1950
21.000	1950-1951
22.000	1951
23.000	1951-1952
24.000	1952-1953
25.000	1953
26.000	1954
27.000	1954-1955
28.000	1955-1956
29.000	1956-1957
30.000	1957
31.000	1958
32.000	1959
33.000	1959-1960
34.000	1960
35.000	1961-1962
36.000	1962-1963
39.000	1964
41.000	1965
44.000	1966
47.000	1967
49.000	1968
52.000	1969
54.600	1970
57.500	1971
59.000	1972
59.500-	1973-1976

Efter 1973 går det ej att göra någon uppdelning.

